



motorola

QUICK START GUIDE


For a full explanation of all features and instructions, please refer to the User's Guide.

1. Setting up your Digital Video Pet Monitor

MODELS:


SCOUT600,
SCOUT600/2,
SCOUT600/3,
SCOUT600/4

A. Connecting power supply for the Pet unit




Connect the small plug of the power adapter to the pet unit and the other end to the electrical outlet. Only use the enclosed adapter (6V DC / 500mA).

B. Installing the battery pack for the Owner unit




Insert the wire tab of the rechargeable battery pack into the contact slot as shown above and fit the battery pack into the compartment.

C. Fastening the cover for the Owner unit



Small cross head or Flat end screw driver.

D. Connecting power supply for the Owner unit










Connect the small plug of the power adapter to the owner unit and the other end to the electrical outlet. Only use the enclosed adapter (6V DC / 500mA).

WARNING:

STRANGULATION HAZARD - In case this unit is being to monitor infants or children, keep the unit and adapter cord more than 3 feet from the crib and out of their reach. Never place camera or cords within a crib or near a bed. Secure the cord away from children's reach. Never use extension cords with AC Adapters. Only use the AC Adapters provided.

As with any electrical device, supervision of your pet's usage should be exercised until your pet is acclimated to the product. If your pet is prone to chewing, we strongly recommend you keep this and all other electrical devices out of its reach.

2. Basic operation of the keys

Owner unit	
 Power ON/OFF button	Press and hold to turn the unit ON/OFF. Press to turn the display ON/OFF.
 UP/VOL+ buttons	Press to increase sound volume. Press to move up menu options/settings. Press to move up in digital pan/tilt mode.
 DOWN/VOL- buttons	Press to decrease sound volume. Press to move down menu options/settings. Press to move down in digital pan/tilt mode.
 MENU/OK button	Press to open menu options. Press to confirm a selection. Press to pan right in digital pan/tilt mode.
 Return/Switch Camera button	Press to return to previous menu level. Press to switch camera units. (If paired with more than one camera) Press to pan left in digital pan/tilt mode.
 Digital Pan/Tilt button	Press to enter/exit digital pan/tilt mode.
 TALK button	Press and hold to speak to your baby.
Pet Unit	
ON/OFF switch	Slide the power switch down to switch on the unit. Slide the power switch up to switch off the unit.

3. General Information

If your product is not working properly...

1. Read this Quick Start Guide or the User's Guide.
2. Contact Customer Service:
US and Canada 1-888-331-3383
Email: motorola@encompass.com



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo, are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. All other trademarks are the property of their respective owners. © 2013 Motorola Mobility LLC. All rights reserved.

Printed in China
Version 4.0