



motorola


QUICK START GUIDE

For a full explanation of all features and instructions, please refer to the User's Guide.

1. Setting up your Digital Video Baby Monitor


MODELS:
MBP36S,
MBP36S-2,
MBP36S-3,
MBP36S-4

A. Connecting power supply for the Baby Unit




Connect the small plug of the power adapter to the Baby Unit and the other end to the electrical outlet. Only use the enclosed adapter (5V DC/1000mA). Ensure the ON/OFF switch is at "ON" position.

B. Installing the battery pack for the Parent Unit




Insert the wire tab of the rechargeable battery pack into the contact slot as shown above and fit the battery pack into the compartment.

C. Fastening the cover for the Parent Unit



Small cross head or Flat end screw driver

D. Connecting power supply for the Parent Unit










Connect the small plug of the power adapter to the parent unit and the other end to the electrical outlet. Only use the enclosed adapter (5V DC / 600mA). Recommend charging at least 12 hours before first use.



WARNING:

STRANGULATION HAZARD - Keep the Unit and adapter cords more than 3 feet from the crib and out of baby's reach. NEVER place camera or cords within the crib. Secure the cords more than 3 feet away from the baby's reach. Never use extension cords with AC Adapters. Only use the AC Adapters provided.

2. Basic operation of the keys

Parent Unit		
	ON/OFF button	Press and hold to switch on/off the Unit.
	UP/DOWN buttons	Press to tilt the camera upward or downward. Press to adjust menu settings.
	LEFT/RIGHT buttons	Press to pan the camera left or right. Press to access different menu options.
	MENU button	Press to open menu options or exit.
	OK button	Press to confirm a selection.
	VIDEO button	Press to turn on/off the LCD display.
	TALK button	Press and hold to talk to your baby.
Baby Unit		
ON/OFF switch		Push power switch to the right to switch on the Unit. Push power switch to the left to switch off the unit.

3. General Information

If your product is not working properly...

1. Read this Quick Start Guide or the User's Guide.
2. Contact Customer Service:
US and Canada 1-888-331-3383
Email: motorola@encompass.com



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo, are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. All other trademarks are the property of their respective owners.

© 2014 Motorola Mobility LLC. All rights reserved.

Printed in China
Version 7.0