


# MBP41, MBP41/2, MBP41/3, MBP41/4 - Quick Start Guide

For a full explanation of all features and instructions, please refer to the User's Guide.


## 1 Setting up your digital baby monitor

### A Connecting power supply for the Baby unit




- Connect the small plug of the power adapter to the baby unit and the other end to the electrical outlet.
- Only use the enclosed adapter (5.9V DC/ 1000mA).

### B Installing the battery pack for the Parent unit




- Insert the wire tab of the rechargeable battery pack into the contact slot as shown above and fit the battery pack into the compartment.

### C Fastening the cover for the Parent unit



Small cross head or Flat end screw driver

### D Connecting power supply for the Parent unit









- Connect the small plug of the power adapter to the parent unit and the other end to the electrical outlet.
- Only use the enclosed adapter (6V DC/500mA).

### ! WARNING:

STRANGULATION HAZARD - Keep the unit and adapter cord more than 3 feet from the crib and out of baby's reach. NEVER place camera or cords within the crib. Secure the cord more than 3 feet away from baby's reach. Never use extension cords with AC Adapters. Only use the AC Adapters provided.

## 2 Basic operation of the keys

Parent unit		
	ON/OFF button	Press and hold to switch on/off the unit.
	UP/DOWN buttons	Press to tilt the camera upward or downward. Press to adjust menu settings.
	LEFT/RIGHT buttons	Press to pan the camera left or right. Press to access different menu options.
	MENU button	Press to open menu options or exit.
<b>OK</b>	OK button	Press to confirm a selection.
	VIDEO button	Press to turn on/off the LCD display.
	TALK button	Press and hold to talk to your baby.
Baby unit		
ON/OFF switch		Push power switch to the right to switch on the unit. Push power switch to the left to switch off the unit.

## 3 General Information

### If your product is not working properly...

1. Read this Quick Start Guide or the User's Guide.
2. Visit our website: [www.motorola.com](http://www.motorola.com)
3. Contact Customer Service:  
US and Canada 1-888-331-3383



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo, are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. All other trademarks are the property of their respective owners.

© 2013 Motorola Mobility LLC. All rights reserved.

Printed in China  
Version 2.0

