

VERVE
CAM/CAM+
Action
Accessories
Pack

User Guide



Your Action Pack



VerveCam Tag



Bike Mount



Head Mount



Helmet Mount

Box Contents


- VerveCam Tag with pre-installed CR2032 battery and VerveCam Tag opener
- Bike Mount
- Head Mount
- Helmet Mount

Additional accessories can be purchased separately from www.verve.life

VerveCam Tag

VerveCam Tag works as a remote control for your camera. You can pair VerveCam Tag with multiple cameras.

Remove Plastic Strip to Power On



The device uses a replaceable battery (CR2032). The average battery life is up to 6 months. Replace the battery if VerveCam Tag does not respond

Replace VerveCam Tag Battery


1. Remove the battery cover using the supplied opener.
2. Slip the opener into the slot on the back of VerveCam Tag.



3. Gently twist the opener to pop open the cover. Once the cover starts to open, work your way carefully around the cover until it pops off.





4. Insert the battery (model: CR2032) with positive pole (+) facing upwards into the battery compartment.




5. Position the back cover over the battery compartment and press down around the edges until you hear it click into its place.
6. VerveCam Tag powers on automatically when the battery is installed correctly.

Pair VerveCam Tag with your Camera



1. Keep the camera in power down mode.
To power down the camera, hold down the **POWER / MODE** button  for 3 seconds. You will hear a voice prompt indicating that the camera is powering off before the LED indicator goes off.



2. Hold down the camera's **SHUTTER/ SELECT** button  for 3 seconds to enter pairing mode.
The LED indicator flashes in RED and BLUE.
3. Hold down the **PAIR/SHUTTER** button on VerveCam Tag for 3 seconds to start pairing.
4. Once paired, VerveCam Tag will emit 2 beep tones and the LED indicator on the camera stops flashing.

Un-Pair VerveCam Tag with your Camera

When VerveCam Tag is paired with the camera:

1. Press the **SHUTTER/SELECT** button  on the camera to stop pairing.
2. Hold down the **SHUTTER/SELECT** button  on the camera for 2 seconds to unpair it with VerveCam Tag.

Using VerveCam Tag as a Remote Control

The **PAIR/SHUTTER** button on VerveCam Tag works like the **SHUTTER/SELECT** button  on your camera.

You can press the **PAIR/SHUTTER** button on VerveCam Tag to:

- **Take photo**
- **Start and Stop video recording**
- **Wake up the camera from standby mode**

Make sure that the camera is powered On or in Standby mode. VerveCam Tag cannot wake up the camera when it is powered off.

With VerveCam Tag, you can shoot remotely up to approximately 20 meters (65 feet) away from the camera.

If you have paired VerveCam Tag with multiple cameras, pressing the **PAIR/SHUTTER** button on VerveCam Tag can trigger all the paired cameras to take photo or video at once.

Bike Mount

The Bike Mount fits most bicycle handlebars measuring up to 30 - 31.8 mm in diameter.



A



B




C

1. Release the 2 screws on each end of mounting bracket **(A)** with the supplied allen key **(C)**.
2. Fix the mounting bracket **(A)** onto the handlebar of your bike and secure the other part of the mounting bracket by tightening the 2 screws back in place. Make sure to align the swivel side to the front of your bike.
3. With the waterproof casing or universal tripod mount fixed onto the camera, fasten the camera mount **(B)** to the waterproof casing or universal tripod mount.
4. Release the screw from the swivel end of mounting bracket **(A)** with the allen key **(C)** and slot in the camera mount **(B)**.
5. Tighten the screw back into the swivel end of the mounting bracket **(A)**.
6. You can now turn on the camera and adjust the viewing angle accordingly.

Head Mount

Capture photos or the videos while reeling in your big catch or playing with your pets has never been easier. The Head Mount can be used for any activities where you need to be “hands free” from your camera.



(share with Helmet Mount)

1. Put on the Head Strap **(A)** and adjust the length of the strap so that it fits your head comfortably.
2. With the waterproof casing or universal tripod mount fixed onto the camera, fasten the camera mount **(B)** to the waterproof casing or universal tripod mount.
3. Slot the swivel end of the camera mount **(B)** into the swivel end of the head strap **(A)**.
4. Use the bolt **(C)** to fasten the swivel ends to secure the whole assembly.
5. You can now turn on the camera and adjust the viewing angle accordingly.

Helmet Mount

Capture every moment while you are rock climbing or even sky diving.



A



B



C



D

(share with Head Mount)

1. Wrap the helmet strap **(A)** around your helmet and secure it tightly using the buckle provided.
2. Fasten the clip **(B)** to Helmet strap **(A)**.
3. With the waterproof casing or universal tripod mount fixed onto the camera, fasten the camera mount **(D)** to the waterproof casing or universal tripod mount.
4. Slot the swivel end of the camera mount **(D)** into the swivel end of clip **(B)**.
5. Use the bolt **(C)** to fasten the swivel ends to secure the whole assembly.
6. You can now turn on the camera and adjust the viewing angle accordingly.

Help & more

If your product is not working properly....

1. Read this User Guide.
2. Visit our website: www.verve.life/contact
3. Contact Customer Service at

For UK:	+44 (0) 844 557 0890 (UK only)* <i>*Calls cost 7p per minute plus your telephone company's access charge</i> +44 (0) 8187 62092 (ROI)	
For Europe:	+49 (0) 1805 938 802	
For South Africa:	Safe Motion Solutions	011 7917225
For Dubai:	Life Time Trendz General Trading LLC	info@lifetrendzme.com +971 4 321 6166
For Turkey:	Müşteri Hizmetleri	teknikservis@oztelkum.com.tr +90 212 297 35 00
For Singapore:	Alcom SG	+65 6841 2668
For Hong Kong:	HK Good Century	+(852)3619 6499
For China:	China MT Digital	400-889-9090

Consumer Products and Accessories Limited Warranty

Thank you for purchasing this Motorola branded product manufactured under license by Binatone Electronics International LTD ("BINATONE").

What Does this Warranty Cover?

Subject to the exclusions contained below, BINATONE warrants that this Motorola branded product ("Product") or certified accessory ("Accessory") sold for use with this product that it manufactured to be free from defects in materials and workmanship under normal consumer usage for the period outlined below. This Warranty is your exclusive warranty and is not transferable.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY HAVE OTHER RIGHTS THAT VARY BY STATE, PROVINCE OR COUNTRY. FOR CONSUMERS WHO ARE COVERED BY CONSUMER PROTECTION LAWS OR REGULATIONS IN THEIR COUNTRY OF PURCHASE OR, IF DIFFERENT, THEIR COUNTRY OF RESIDENCE, THE BENEFITS CONFERRED BY THIS LIMITED WARRANTY ARE IN ADDITION TO ALL RIGHTS AND REMEDIES CONVEYED BY SUCH CONSUMER PROTECTION LAWS AND REGULATIONS. FOR A FULL UNDERSTANDING OF YOUR RIGHTS YOU SHOULD CONSULT THE LAWS OF YOUR COUNTRY, PROVINCE OR STATE.

Who is covered?

This Warranty extends only to the first consumer purchaser, and is not transferable.

What will BINATONE do?

BINATONE or its authorised distributor at its option and within a commercially reasonable time, will at no charge repair or replace any Products or Accessories that do not conform to this Warranty. We may use functionally equivalent reconditioned/ refurbished/ pre-owned or new Products, Accessories or parts.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR OR REPLACEMENT PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA OR BINATONE BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR ACCESSORY, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS OR ACCESSORIES TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may also have other rights that vary from one jurisdiction to another.

Products Covered	Length of Coverage
Consumer Products	One (1) year from the date of the products original purchase by the first consumer purchaser of the product.
Consumer Accessories	Ninety (90) days from the date of the accessories original purchase by the first consumer purchaser of the product.
Consumer Products and Accessories that are Repaired or Replaced	The balance of the original warranty or for Ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this Warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of MOTOROLA or BINATONE, are excluded from coverage.

Use of Non-Motorola branded Products and Accessories.

Defects or damage that result from the use of Non-Motorola branded or certified Products or Accessories or other peripheral equipment are excluded from coverage.

Unauthorised Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than MOTOROLA, BINATONE or its authorised service centres, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola branded housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products or Accessories due to any communication service or signal you may subscribe to or use with the Products or Accessories is excluded from coverage.

How to Obtain Warranty Service or Other Information?

To obtain service or information, please call:

For UK:	+44 (0) 844 557 0890 (UK only)* <i>*Calls cost 7p per minute plus your telephone company's access charge</i> +44 (0) 8187 62092 (ROI)	
For Europe:	+49 (0) 1805 938 802	
For South Africa:	Safe Motion Solutions	011 7917225
For Dubai:	Life Time Trendz General Trading LLC	info@lifetrendzme.com +971 4 321 6166
For Turkey:	Müşteri Hizmetleri	teknikservis@oztelkum.com.tr +90 212 297 35 00
For Singapore:	Alcom SG	+65 6841 2668
For Hong Kong:	HK Good Century	+(852)3619 6499
For China:	China MT Digital	400-889-9090

You will receive instructions on how to ship the Products or Accessories at your expense and risk, to a BINATONE Authorised Repair Centre.

To obtain service, you must include: (a) the Product or Accessory; (b) the original proof of purchase (receipt) which includes the date, place and seller of the Product; (c) if a warranty card was included in your box, a completed warranty card showing the serial number of the Product; (d) a written description of the problem; and, most importantly; (e) your address and telephone number.

These terms and conditions constitute the complete warranty agreement between you and BINATONE regarding the Products or Accessories purchased by you, and supersede any prior agreement or representations, including representations made in any literature publications or promotional materials issued by BINATONE or representations made by any agent employee or staff of BINATONE, that may have been made in connection with the said purchase.



CE DECLARATION

This product is in compliance with the essential requirements and other relevant provisions of the R&TTE directive 1999/5/EC.

Download User Guide from website: www.verve.life



www.motorolahome.com
www.verve.life

	<p>RECYCLING This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimise its impact on the environment. User has the choice to give his product to a competent recycling organisation or to the retailer when he buys a new electrical or electronic equipment.</p>
	<p>DC Voltage</p>

Manufactured, distributed, or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylised M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. Apple logo is a trademark of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google Play and Android are trademarks of Google Inc. All other trademarks are the property of their respective owners. © 2017 Motorola Mobility LLC. All rights reserved.



UK_EU_ROW_EN Version 1.0
Printed in China

Model number: CA001-AP