


# MBP18, MBP18/2, MBP18/3, MBP18/4 - Quick Start Guide

For a full explanation of all features and instructions, please refer to the User's Guide.


## 1 Setting up your digital baby monitor

### A Connecting power supply for the Baby unit




- Connect the small plug of the power adapter to the baby unit and the other end to the electrical outlet.
- Only use the enclosed adapter (6V DC / 500mA).

### B Installing the battery pack for the Parent unit




- Insert the wire tab of the rechargeable battery pack into the contact slot as shown above and fit the battery pack into the compartment.

### C Fastening the cover for the Parent unit










Small cross head or Flat end screw driver.

### D Connecting power supply for the Parent unit



- Connect the small plug of the power adapter to the parent unit and the other end to the electrical outlet.
- Only use the enclosed adapter (6V DC / 500mA).

## 2 Basic operation of the keys

Parent unit	
  Ú[ , ^! ÁON/OFF button Xã^! ÁON/OFF button	Press and hold to turn the unit ON/OFF. Press to turn the LCD display ON/OFF.
 UP/VOL+ buttons	Press to increase sound volume. Press to move up menu options/settings. Press to move up in 2X zoom mode.
 DOWN/VOL- buttons	Press to decrease sound volume. Press to move down menu options/settings. Press to move down in 2X zoom mode.
 MENU/OK button	Press to open menu options. Press to confirm a selection. Press to pan right in 2x zoom mode.
 Return/Switch Camera button	Press to return to previous menu level. Press to switch camera units. (If paired with more than one camera) Press to pan left in 2x zoom mode.
 ZOOM button	Press to enter / exit to 2x zoom mode. Press again to return to normal view (1x).
Baby unit	
ON/OFF switch	Slide the power switch down to switch on the unit. Slide the power switch up to switch off the unit.

## 3 General Information

### If your product is not working properly...

1. Read this Quick Start Guide or the User's Guide.
2. Contact Customer Service:

WS/WE I Í Á FÌ Á J E  
 ÜU ÜÜ FÌ Í Á G E J G



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo, are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. All other trademarks are the property of their respective owners.

© 2013 Motorola Mobility LLC. All rights reserved.

Printed in China  
 Version 2.0

