


# MBP26, MBP26/2, MBP26/3, MBP26/4 - Quick Start Guide

For a full explanation of all features and instructions, please refer to the User's Guide.


## 1 Setting up your digital baby monitor

### A Connecting power supply for the Baby unit




- Connect the small plug of the power adapter to the baby unit and the other end to the electrical outlet.
- Only use the enclosed adapter (6V DC / 500mA).

### B Installing the battery pack for the Parent unit




- Insert the wire tab of the rechargeable battery pack into the contact slot as shown above and fit the battery pack into the compartment.

### C Fastening the cover for the Parent unit



Small cross head or Flat end screw driver.

### D Connecting power supply for the Parent unit










- Connect the small plug of the power adapter to the parent unit and the other end to the electrical outlet.
- Only use the enclosed adapter (6V DC / 500mA).

### ! WARNING:

STRANGULATION HAZARD - Keep the unit and adapter cord more than 1 meter from the cot and out of baby's reach. NEVER place camera or cords within the cot. Secure the cord more than 1 meter away from baby's reach. Never use extension cords with AC Adapters. Only use the AC Adapters provided.

## 2 Basic operation of the keys

Parent unit		
	ON/OFF button	Press and hold to turn the unit ON/OFF. Press to turn the display ON/OFF.
	UP/VOL+ buttons	Press to increase sound volume. Press to move up menu options/settings. Press to move up in digital pan/tilt mode.
	DOWN/VOL- buttons	Press to decrease sound volume. Press to move down menu options/settings. Press to move down in digital pan/tilt mode.
	MENU/OK button	Press to open menu options. Press to confirm a selection. Press to pan right in digital pan/tilt mode.
	Return/Switch Camera button	Press to return to previous menu level. Press to switch camera units. (If paired with more than one camera) Press to pan left in digital pan/tilt mode.
	Digital Pan/Tilt button	Press to enter/exit digital pan/tilt mode.
	TALK button	Press and hold to speak to your baby.
Baby unit		
	ON/OFF switch	Slide the power switch down to switch on the unit. Slide the power switch up to switch off the unit.

## 3 General Information

### If your product is not working properly...

1. Read this Quick Start Guide or the User's Guide.
2. Contact Customer Service:  
UK 0845 218 0890  
ROI 08187 62092



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo, are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. All other trademarks are the property of their respective owners.

© 2013 Motorola Mobility LLC. All rights reserved.

Printed in China  
Version 3.0

