



motorola

QUICK START GUIDE


For a full explanation of all features and instructions, please refer to the User's Guide.

1. Setting up your Digital Video Baby Monitor

MODELS:


MBP854HD,
MBP854HD-2,
MBP854HD-3,
MBP854HD-4

A. Connecting power supply for the Baby Unit



Connect the micro USB plug of the power adapter to the Baby Unit and the other end to a suitable mains power socket.
Only use the enclosed adapter (5Vdc/1500mA). Ensure the ON/OFF switch is at "ON" position.

B. Installing the battery pack for the Parent Unit



Connect the micro USB plug of the power adapter to the parent unit and the other end to a suitable mains power socket. Only use the enclosed adapter (5Vdc/1500mA). Recommend charging at least 16 hours before

C. Install "Hubble for Motorola Monitors" App.



Download the "Hubble for Motorola Monitors" App from the App Store for iOS® devices or from the Google Play™ Store for Android™ devices.




WARNING:

STRANGULATION HAZARD - Keep the Unit and adapter cords more than 1 metre from the cot and out of baby's reach. NEVER place camera or cords within the cot. Secure the cords more than 1 metre away from the baby's reach. Never use extension cords with AC Adapters. Only use the AC Adapters provided.

D. View on Compatible Smartphones, Tablets and Computers.



1. Run the Hubble for Motorola Monitors App  on smartphones or tablets.
2. Follow the in-app instructions to create your Hubble for Motorola Monitors account.
3. Log in to your account on your compatible smartphone, tablet or via www.hubbleconnected.com/motorola/login on your PC to access your live camera stream.










Please take note of the following system requirements:

Android 4.0 or above. For iPhone /iPad iOS, it requires version 7.0 or above.

Windows systems, 7 or 8 (Java browser plug in needed) or Mac OS version 10.7 or above.

You must have a required browser version Internet Explorer 8.0 or higher, Safari 4.0 or higher, Mozilla Firefox 3.0 or higher or Google Chrome.

2. Basic operation of the keys

Parent Unit		
	ON/OFF button	Press and hold to switch on/off the Unit.
	UP/DOWN buttons	Press to tilt the camera upward or downward. Press to adjust menu settings.
	LEFT/RIGHT buttons	Press to pan the camera left or right. Press to access different menu options.
	MENU button	Press to open menu options or exit.
	OK button	Press to confirm a selection.
	VIDEO button	Press to turn on/off the LCD display.
	TALK button	Press and hold to talk to your baby.
	Volume button	Press -/+ to select volume level.
Baby Unit		
	ON/OFF switch	Push power switch to the right to switch on the Unit. Push power switch to the left to switch off the Unit.

3. Customer Support

If you are experiencing any issues with your Motorola Wi-Fi[®] Home Video Camera, please visit the help section on our website www.motorola.com.

You can also contact our customer support teams

+44 (0) 844 557 0890 (UK only)

+44 (0) 8187 62092 (ROI)



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo, are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. Mac, Mac OS, iPhone, iPad and Safari are the trademarks of Apple Inc., registered in the U.S. and other countries. Android, Google Play and Chrome are trademarks of Google Inc. Wi-Fi is trademark of the Wi-Fi Alliance. Window XP and Internet Explorer are trademarks of the Microsoft group of companies. Oracle and Java are registered trademarks of Oracle and/or its affiliates. All other trademarks are the property of their respective owners.

© 2014 Motorola Mobility LLC. All rights reserved.



Printed in China

EN_UK Version 2.0