



motorola


# QUICK START GUIDE

For a full explanation of all features and instructions, please refer to the User's Guide.

## 1. How to register your Camera to Hubble account

MODELS:  
FOCUS73  
FOCUS73-2

### A. Connect to power supply.



1. Connect the Camera's round plug to the Y-shaped Power/LAN cable connector.
2. Insert the power adapter plug into the power socket and connect the other end of the power adapter to a suitable mains power socket.
3. The Camera turns ON, and the LED indicator will start flashing slowly after booting finish.

### B. Install Hubble for Motorola Monitors App.



Download the Hubble for Motorola Monitors App from the App Store for iOS® devices or from the Google Play™ Store for Android™ devices.



### WARNING:


**STRANGULATION HAZARD** – In case this unit is being used to monitor infants or children, keep the unit and adapter cord more than 1 metre from the cot and out their reach.

Never place camera or cords inside a cot or near a bed. Secure the cord away from the reach of children. Never use extension cords with AC Adapters. Only use the AC Adapters provided.

As with any electrical device, supervision of your pet's usage should be exercised until your pet is acclimated to the product. If your pet is prone to chewing, we strongly recommend you keep this and all other electrical devices out of its reach.

## C. View on Compatible Smartphones, Tablets and Computers.



1. Open the Hubble for Motorola Monitors App  on your compatible smartphone or tablet.
2. Follow the in-app instructions to create your Hubble account and connect to your Wi-Fi Camera.
3. Log in to your account on your compatible smartphone, tablet or via <https://app.hubbleconnected.com/#login> on your PC to access your live camera stream.

Please take note of the following minimum system requirements:

Smartphones/Tablets: iOS 7, Android™ 4.2


PC (only for viewing - NOT setup): Windows® 7, Mac OS® 10.7, Chrome™ 24, Internet Explorer® 9, Safari® 6, Firefox® 18, Adobe® Flash® 15, Java™ 7

Wi-Fi requirements:

At least 0.6 Mbps upload bandwidth per camera. Test your Internet speed at: <http://www.speedtest.net/>


## 2. How to mount your Camera on the wall

### A. Fixing Mounting Plate on the wall.




1. Mark the position of the screw holes on the wall.
2. Drill 4 holes and hammer the drywall plugs (included) into the holes as needed.
3. Fasten the mounting plate on the wall with the 4 Philips head screws (provided).

### B. Hanging the Camera unit on the Mounting Plate.



Place the 4 mounting slots of the camera base on to 4 catches on the mounting plate. Make sure the unit sits firmly on the mounting plate with the center holes of 2 parts lined up.

### C. Secure the Camera Unit.



Fasten the unit to the mounting plate at the center hole with the tamper-proof screw by the wrench key provided.

### D. Connecting Power Supply for the Camera Unit.



Insert the power adapter plug into the Power Socket and connect other end of the power adapter to a suitable mains power socket.

## 3. Customer Support

If you are experiencing any issues with your Motorola Wi-Fi<sup>®</sup> Outdoor Home Video Camera, please visit the help section on our website [www.motorola.com](http://www.motorola.com)

**You can also contact our customer support teams**

+44 (0) 844 557 0890 (UK only)

+44 (0) 8187 62092 (ROI)



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. Apple logo and Safari are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google Play, Android, and Chrome are trademarks of Google Inc. Wi-Fi is a trademark of the Wi-Fi Alliance. Internet Explorer and Windows are trademarks of the Microsoft group of companies. Firefox is a registered trademark of the Mozilla Foundation. Adobe and Flash are either registered trademarks or trademarks of Adobe Systems Incorporated. Java is a registered trademark of Oracle and/or its affiliates. All other trademarks are the property of their respective owners.  
© 2015 Motorola Mobility LLC. All rights reserved.



Printed in China

EN\_UK Version 11.0