


VERVE CAM VERVE CAM+

Quick Start Guide

For detailed operating instructions, refer to the User Manual which can be downloaded from www.verve.life



Your Camera



1. Camera LED (Blue / Red)
2. Microphone
3. Camera Lens
4. Speaker
5. micro SD Card* Slot and Reset Button (*micro SD Card is not included.*)
6. Power / Mode Button
7. Mode Indicators (Photo / Video / Streaming)
8. Shutter / Select Button
9. Lanyard Hole
10. Locking Holes
11. micro-USB socket

* supports microSDHC cards up to 32GB.


Accessories included with Verve CAM+

Waterproof Case • Clip Mount • Bumper & lanyard • Universal Tripod Mount

Additional accessories for other home or outdoor activities can be purchased separately from www.verve.life

Step 1: Setting up


Charge the Battery




Connect the power adapter to a mains power socket and insert the plug into the micro-USB socket on the underside of the Camera. Only use the power adapter (5V 1A) with the micro-USB plug.

Note: *If the Camera is OFF, the LED indicator lights up in red when charging and goes off when the battery is fully charged. It takes about 6 hours to fully charge the battery for the first time.*

Power On & Off the Camera

To power ON the Camera, hold down the **POWER / MODE** button  for 3 seconds. The LED indicator lights up in blue.

To power OFF the Camera, hold down the **POWER / MODE** button  for 3 seconds. You will hear a voice prompt indicating that the Camera is powering off before the LED indicator goes off.

Step 2: Connecting Devices

Download & Install *Hubble Connect for VerveCam* app

Download & Install *Hubble Connect for VerveCam* app on your smartphone for free at the App Store[®] or Google Play[™].

Pair the Camera with your Smartphone

1. Run *Hubble Connect for VerveCam* app on your smartphone.
2. Follow the in-app instructions to connect the Camera with your smartphone.
3. The Camera ID is printed on the back of the Camera. **YOUR CAMERA'S DEFAULT PASSWORD IS "00000000".**

Please take note of the following minimum system requirements:












Smartphone: iOS 7 (and higher) or Android[™] 4.3 (and higher)

Not supported on iPad and Android tablets.

Wi-Fi[®] requirements:

At least 2Mbps upload bandwidth per camera. Test your Internet speed at: <http://www.speedtest.net/>

Basic Operation of your Camera

To	Do this
Take photo	<ol style="list-style-type: none">1. Press the POWER / MODE button  repeatedly until the photo mode indicator  lights up.2. Press the SHUTTER/SELECT button  to take photo.
Record Video	<ol style="list-style-type: none">1. Press the POWER / MODE button  repeatedly until the video mode indicator  lights up.2. Press the SHUTTER/SELECT button  to start recording.3. Press the SHUTTER/SELECT button  again to stop recording.
Record Time-lapse video	<ol style="list-style-type: none">1. Run Hubble Connect for VerveCam app on your smartphone and make sure that the Camera is connected.2. In the viewfinder screen, tap to select Time Lapse mode  on the bottom panel.
Start Loop Recording	<ol style="list-style-type: none">1. Run Hubble Connect for VerveCam app on your smartphone and make sure that the Camera is connected.2. In the viewfinder screen, tap to select Loop Record mode  on the bottom panel.
Start Livestream	<ol style="list-style-type: none">1. Run Hubble Connect for VerveCam app on your smartphone and make sure that the Camera is connected.2. In the viewfinder screen, tap to select Livestream mode  on the bottom panel.3. Follow the in-app instructions to setup livestream.
View Photos and Videos	<ol style="list-style-type: none">1. Run Hubble Connect for VerveCam app on your smartphone and make sure that the Camera is connected.2. Go to Camera roll mode .

Transfer files from the Camera to your Computer

Power on the Camera and make sure that the Camera is disconnected from **Hubble Connect for VerveCam** app.

To disconnect the Camera from the app, you can close the app or turn off the Camera and turn it on again.

Connect the Camera to your computer's USB port. Your computer will recognise the Camera as a mass storage device. You can then drag and drop your files, just like other external devices.

To exit mass storage mode, unplug the USB cable.

Help & more

If your product is not working properly....

1. Read this Quick Start Guide or the User Manual.
2. Visit our website: www.verve.life/contact
3. Contact Customer Service at

+491805 938 802 (Europe)

E-mail: support@verve.life

Consumer Products and Accessories Limited Warranty

Thank you for purchasing this Motorola branded product manufactured under license by Binatone Electronics International LTD ("BINATONE").

What Does this Warranty Cover?

Subject to the exclusions contained below, BINATONE warrants that this Motorola branded product ("Product") or certified accessory ("Accessory") sold for use with this product that it manufactured to be free from defects in materials and workmanship under normal consumer usage for the period outlined below. This Warranty is your exclusive warranty and is not transferable.

Who is covered?

This Warranty extends only to the first consumer purchaser, and is not transferable.

What will BINATONE do?

BINATONE or its authorised distributor at its option and within a commercially reasonable time, will at no charge repair or replace any Products or Accessories that does not conform to this Warranty. We may use functionally equivalent reconditioned/ refurbished/ pre-owned or new Products, Accessories or parts.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION

THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR OR REPLACEMENT PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA OR BINATONE BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR ACCESSORY, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS OR ACCESSORIES TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW. Some jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may also have other rights that vary from one jurisdiction to another.

Products Covered	Length of Coverage
Consumer Products	Two (2) years from the date of the products original purchase by the first consumer purchaser of the product.
Consumer Accessories	Ninety (90) days from the date of the accessories original purchase by the first consumer purchaser of the product.
Consumer Products and Accessories that are Repaired or Replaced	The balance of the original warranty or for Ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this Warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the

fault of MOTOROLA or BINATONE, are excluded from coverage.

Use of Non-Motorola branded Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products or Accessories or other peripheral equipment are excluded from coverage.

Unauthorised Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than MOTOROLA, BINATONE or its authorised service centres, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola branded housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products or Accessories due to any communication service or signal you may subscribe to or use with the Products or Accessories is excluded from coverage.

How to Obtain Warranty Service or Other Information?

To obtain service or information, please call:

+491805 938 802 (Europe)

E-mail: support@verve.life

You will receive instructions on how to ship the Products or Accessories at your expense and risk, to a BINATONE Authorised Repair Centre.

To obtain service, you must include: (a) the Product or Accessory; (b) the original proof of purchase (receipt) which includes the date, place and seller of the Product; (c) if a warranty card was included in your box, a completed warranty card showing the serial number of the Product; (d) a written description of the problem; and, most importantly; (e) your address and telephone number.

These terms and conditions constitute the complete warranty agreement between you and BINATONE regarding the Products or Accessories purchased by you, and supersede any prior agreement or representations, including representations made in any literature publications or promotional materials issued by BINATONE or representations made by any agent employee or staff of BINATONE, that may have been made in connection with the said purchase.

CE DECLARATION



This product is in compliance with the essential requirements and other relevant provisions of the R&TTE directive 1999/5/EC.

Download User Guide from website: www.verve.life



www.motorolahome.com

www.verve.life

	<p>RECYCLING</p> <p>This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimise its impact on the environment. User has the choice to give his product to a competent recycling organisation or to the retailer when he buys a new electrical or electronic equipment.</p>
	<p>DC Voltage</p>

Manufactured, distributed, or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylised M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. Apple logo is a trademark of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google Play and Android are trademarks of Google Inc. All other trademarks are the property of their respective owners. © 2016 Motorola Mobility LLC. All rights reserved.



EU_EN Version 1.0
Printed in China
Model number: CA001