



motorola

MODEL:
SCOUT5000

! WARNING:

As with any electrical device, supervision of your pet's usage should be exercised until your pet is acclimated to the product. If your pet is prone to chewing, we strongly recommend that you keep this and all other electrical devices out of its reach.

Minimum System Requirements:

Smartphones/Tablets: iOS 7, Android™ 4.2.
Wi-Fi requirements: At least 0.6 Mbps upload bandwidth per camera.
Test your Internet speed at: <http://www.speedtest.net/>


QUICK START GUIDE

US EN

For a full explanation of all features and instructions, please refer to the User's Guide.

1. Setting up your Pet Camera

A. Charging the Pet Camera



- Connect the power adapter to an electrical outlet and insert the plug into the micro USB socket on the Pet Camera.
- Only use the supplied power adapter (5V DC / 1000mA) with the Micro USB plug. The status indicator LED lights up in solid red, which indicates that it is charging.

B. Powering the Pet Camera ON/OFF

- To power on the Pet Camera, press and hold the POWER KEY for approximately 3 seconds. The LED lights up in solid green and a melody is played.
- To power off the Pet Camera, press and hold the POWER KEY for approximately 3 seconds until a melody is played. The LED lights up in solid green before it goes off.

2. Setting Up the Pet Camera for Wi-Fi® Internet Viewing

A. Install Hubble for Petcam App



Download Hubble for Petcam App from the App Store for iOS® devices or from the Google Play™ Store for Android™ devices.

B. View on Compatible Smartphones and Tablets







1. Open the Hubble for Petcam App on your compatible smartphone or tablet.
2. Follow the in-app instructions to create your Hubble account and connect to your Pet Camera.
3. Log in to your Account on your compatible smartphone or tablet to access your live camera stream.

3. Modes of Operation

- **Wi-Fi® Local (Your smartphone or tablet connects to the Pet Camera via local Wi-Fi® Access Point or your home Wi-Fi® network)**



As long as the Pet Camera is on your home Wi-Fi® network, you can check on your dog from anywhere you have an internet connection.

In this mode, you can take pictures , record videos  and send reward  or warning  messages to your dog via the 2-way communication feature.




- **Wi-Fi® Direct (Your smartphone or tablet connects directly to the Pet Camera)**

Want to take your dog for a walk or go to the dog park and still be able to take pictures  or videos  ?











Simply connect via Wi-Fi Direct while on your home network and off you go!

In this mode, you can use the GPS location tracking function  to see where you are going on the map view. You can also set up Geo Fencing  to receive alerts if your dog ventures out of the virtual boundary. (your smartphone/tablet and the Pet Camera must be within 300 feet (100 meters) of each other for this function to work)

- **Mobile (Your smartphone or tablet connects to Pet Camera via 2G/GPRS)**

Away from home? That's not a problem at all! The Pet Camera will automatically switch to mobile mode to connect to your smart device. While you can't view live video in this mode, you can still take pictures  and record videos  of what your dog is seeing. You can also use GPS Tracking  to know where your dog is at all times. The Pet Camera comes with a free 1-year subscription for mobile network connection. (see the User Guide for more information)

4. Main functions of the Pet Camera

		Wi-Fi® Local	Wi-Fi® Direct	Mobile
Live streaming		√	√	x
Record videos		√	√	√
Take pictures		√	√	√
LED torch		√	√	x
Download pictures & videos		√	√	x
Share pictures & videos		√	x	x
2-way communication		√	√	x
Playback pre-recorded reward or warning messages	 	√	√	√
Location view (mobile, GPS)		x	√	√
Geo Fencing (GPS)		x	√	√

5. General Information

If your product is not working properly, read this Quick Start Guide or the User's Guide of one of the models listed on page 1.

Contact Customer Service:

US and Canada 1-888-331-3383

Email: help@motorolahome.com

Consumer Products and Accessories Limited Warranty ("Warranty")

Thank you for purchasing this Motorola branded product manufactured under license by Binatone Electronics International LTD ("BINATONE").

What Does this Warranty Cover?

Subject to the exclusions contained below, BINATONE warrants that this Motorola branded product ("Product") or certified accessory ("Accessory") sold for use with this product that it manufactured to be free from defects in materials and workmanship under normal consumer usage for the period outlined below. This Warranty is your exclusive warranty and is not transferable.

Who is covered?

This Warranty extends only to the first consumer purchaser, and is not transferable.

What will BINATONE do?

BINATONE or its authorized distributor at its option and within a commercially reasonable time, will at no charge repair or replace any Products or Accessories that does not conform to this Warranty. We may use functionally equivalent reconditioned/ refurbished/ pre-owned or new Products, Accessories or parts.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR OR REPLACEMENT PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA OR BINATONE BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR ACCESSORY, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS OR ACCESSORIES TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may also have other rights that vary from one jurisdiction to another.

Products Covered	Length of Coverage
Consumer Products	One (1) year from the date of the products original purchase by the first consumer purchaser of the product.
Consumer Accessories	Ninety (90) days from the date of the accessories original purchase by the first consumer purchaser of the product.
Consumer Products and Accessories that are Repaired or Replaced	The balance of the original warranty or for Ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this Warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of MOTOROLA or BINATONE, are excluded from coverage.

Use of Non-Motorola branded Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products or Accessories or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than MOTOROLA, BINATONE or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola branded housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products or Accessories due to any communication service or signal you may subscribe to or use with the Products or Accessories is excluded from coverage.

How to Obtain Warranty Service or Other Information?

To obtain service or information, please call:

US and Canada 1-888-331-3383

Email: help@motorolahome.com

You will receive instructions on how to ship the Products or Accessories at your expense and risk, to a BINATONE Authorized Repair Center. To obtain service, you must include: (a) the Product or Accessory; (b) the original proof of purchase (receipt) which includes the date, place and seller of the Product; (c) if a warranty card was included in your box, a completed warranty card showing the serial number of the Product; (d) a written description of the problem; and, most importantly; (e) your address and telephone number.

These terms and conditions constitute the complete warranty agreement between you and BINATONE regarding the Products or Accessories purchased by you, and supersede any prior agreement or representations, including representations made in any literature publications or promotional materials issued by BINATONE or representations made by any agent, employee or staff of BINATONE, that may have been made in connection with the said purchase.

FCC and IC regulations (FCC Part 15)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules.

Industry Canada: This device complies with Industry Canada licence-exempt RSS standard(s): Operation is subject to the following Two conditions:(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Download User Guide from website: www.motorolahome.com/help



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. Apple logo and Safari are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google Play, Android, and Chrome are trademarks of Google Inc. Wi-Fi is a trademark of the Wi-Fi Alliance. Internet Explorer and Windows are trademarks of the Microsoft group of companies. Firefox is a registered trademark of the Mozilla Foundation. Adobe and Flash are either registered trademarks or trademarks of Adobe Systems Incorporated. Java is a registered trademark of Oracle and/or its affiliates. All other trademarks are the property of their respective owners. © 2015 Motorola Mobility LLC. All rights reserved.



Printed in China
US_EN Version 4.0