

# **VERVE**

## **CAM/CAM+**

### **Accessory Kit** **Battery Stand and** **Suction Mount**

#### Quick Start Guide

For detailed operating instructions, refer to the User Manual which can be downloaded from [www.verve.life](http://www.verve.life)



# Box Contents

- 1 x Battery Stand
- 1 x Detachable Base (for Battery Stand)
- 1 x Suction Mount
- 5V 1.5A AC/DC micro USB power adapter

*Additional accessories for other home or outdoor activities can be purchased separately from [www.verve.life](http://www.verve.life)*

## Battery Stand & Detachable Base



1. Button for locking the VerveCam
2. VerveCam (not included in the accessory kit, sold separately)
3. Detachable base
4. Battery level button.  
Press to show battery level
5. micro USB socket
6. Battery level indicators
7. Standard universal screw mount.  
The battery stand can work with other accessories, such as window mount, bike mount, helmet mount and head mount.

# Using the Battery Stand

## Attaching the detachable base to the Battery Stand

1. Look for a threaded hole in the bottom of the Battery Stand.
2. Screw the base to the Battery Stand until they are snugly joined.  
The Battery Stand can fully rotate and tilt forward/backward when attached to the base.
3. Screw the Suction Mount to the Battery Stand if you want to put it on the windscreen or window.

## Charging the Battery Stand

1. Connect the supplied power adapter to a mains power socket and insert the plug into the micro USB socket at the back of the Battery Stand.
2. The battery level indicators (3 LEDs) will light up progressively when charging.
3. All the 3 LEDs will light up when it is fully-charged.


## Charging the VerveCam

1. Connect VerveCam to the Battery Stand and lock it securely.
2. Connect the supplied power adapter to mains power socket and insert the plug into the micro USB socket at the back of the Battery Stand.
3. VerveCam and the Battery Stand will be charged at the same time.
4. All the 3 battery level indicators will light up when VerveCam is fully-charged (if the Battery Stand is connected to a mains power socket).

## Checking battery level on the Battery Stand

1. Press the battery level button once.
2. The battery level indicators (3 LEDs) will light up, where 1 LED = LOW, 2 LEDs = MEDIUM, 3 LEDs = HIGH).
3. The battery level indicators will flash 3 times if the Battery Stand is not connected to a mains power socket.

# Suction Mount



The suction mount supports 360 degree tilt, turn and rotation. It comes with a strong suction cup that will adhere to most smooth flat surfaces, and is compatible with most digital cameras that have a standard 1/4" tripod screw mount.

1. Attach your VerveCam to its universal tripod mount.
2. Screw the universal tripod mount to the suction mount and stick the suction cup to a smooth surface.
3. To get extra suction, press down the lever on the suction mount to lock it in place.  
To remove, pull up the lever to release and then use the tab to break the suction.

# Help & more

## If your product is not working properly....

1. Read this Quick Start Guide or the User Manual.
2. Visit our website: [www.verve.life/contact](http://www.verve.life/contact)
3. Contact Customer Service at

<b>For UK:</b>	+44 (0) 844 557 0890 (UK only)* <i>*Calls cost 7p per minute plus your telephone company's access charge</i> +44 (0) 8187 62092 (ROI)	
<b>For Europe:</b>	+49 (0) 1805 938 802	
<b>For South Africa:</b>	Safe Motion Solutions	011 7917225
<b>For Dubai:</b>	Life Time Trendz General Trading LLC	info@lifetrendzme.com +971 4 321 6166
<b>For Turkey:</b>	Müşteri Hizmetleri	teknikservis@oztelkum.com.tr +90 212 297 35 00
<b>For Singapore:</b>	Alcom SG	+65 6841 2668
<b>For Hong Kong:</b>	HK Good Century	+(852)3619 6499
<b>For China:</b>	China MT Digital	400-889-9090

## Consumer Products and Accessories Limited Warranty

Thank you for purchasing this Motorola branded product manufactured under license by Binatone Electronics International LTD ("BINATONE").

### **What Does this Warranty Cover?**

Subject to the exclusions contained below, BINATONE warrants that this Motorola branded product ("Product") or certified accessory ("Accessory") sold for use with this product that it manufactured to be free from defects in materials and workmanship under normal consumer usage for the period outlined below. This Warranty is your exclusive warranty and is not transferable.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY HAVE OTHER RIGHTS THAT VARY BY STATE, PROVINCE OR COUNTRY. FOR CONSUMERS WHO ARE COVERED BY CONSUMER PROTECTION LAWS OR REGULATIONS IN THEIR COUNTRY OF PURCHASE OR, IF DIFFERENT, THEIR COUNTRY OF RESIDENCE, THE BENEFITS CONFERRED BY THIS LIMITED WARRANTY ARE IN ADDITION TO ALL RIGHTS AND REMEDIES CONVEYED BY SUCH CONSUMER PROTECTION LAWS AND REGULATIONS. FOR A FULL UNDERSTANDING OF YOUR RIGHTS YOU SHOULD CONSULT THE LAWS OF YOUR COUNTRY, PROVINCE OR STATE.

### **Who is covered?**

This Warranty extends only to the first consumer purchaser, and is not transferable.

### **What will BINATONE do?**

BINATONE or its authorised distributor at its option and within a commercially reasonable time, will at no charge repair or replace any Products or Accessories that does not conform to this Warranty. We may use functionally equivalent reconditioned/ refurbished/ pre-owned or new Products, Accessories or parts.

### **What Other Limitations Are There?**

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR OR REPLACEMENT PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA OR BINATONE BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR ACCESSORY, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS OR ACCESSORIES TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may also have other rights that vary from one jurisdiction to another.

<b>Products Covered</b>	<b>Length of Coverage</b>
Consumer Products	<b>One (1) year</b> from the date of the products original purchase by the first consumer purchaser of the product.
Consumer Accessories	<b>Ninety (90) days</b> from the date of the accessories original purchase by the first consumer purchaser of the product.
Consumer Products and Accessories that are Repaired or Replaced	<b>The balance of the original warranty or for Ninety (90) days</b> from the date returned to the consumer, whichever is longer.

### **Exclusions**

**Normal Wear and Tear.** Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

**Batteries.** Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this Warranty.

**Abuse & Misuse.** Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of MOTOROLA or BINATONE, are excluded from coverage.

**Use of Non-Motorola branded Products and Accessories.** Defects or damage that result from the use of Non-Motorola branded or certified Products or Accessories or other peripheral equipment are excluded from coverage.

**Unauthorised Service or Modification.** Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than MOTOROLA, BINATONE or its authorised service centres, are excluded from coverage.

**Altered Products.** Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola branded housings, or parts, are excluded from coverage.

**Communication Services.** Defects, damages, or the failure of Products or Accessories due to any communication service or signal you may subscribe to or use with the Products or Accessories is excluded from coverage.

#### **How to Obtain Warranty Service or Other Information?**

To obtain service or information, please call:

<b>For UK:</b>	+44 (0) 844 557 0890 (UK only)* <i>*Calls cost 7p per minute plus your telephone company's access charge</i> +44 (0) 8187 62092 (ROI)	
<b>For Europe:</b>	+49 (0) 1805 938 802	
<b>For South Africa:</b>	Safe Motion Solutions	011 7917225
<b>For Dubai:</b>	Life Time Trendz General Trading LLC	info@lifetrendzme.com +971 4 321 6166
<b>For Turkey:</b>	Müşteri Hizmetleri	teknikservis@oztelkum.com.tr +90 212 297 35 00
<b>For Singapore:</b>	Alcom SG	+65 6841 2668

You will receive instructions on how to ship the Products or Accessories at your expense and risk, to a BINATONE Authorised Repair Centre.

To obtain service, you must include: (a) the Product or Accessory; (b) the original proof of purchase (receipt) which includes the date,



place and seller of the Product; (c) if a warranty card was included in your box, a completed warranty card showing the serial number of the Product; (d) a written description of the problem; and, most importantly; (e) your address and telephone number.

These terms and conditions constitute the complete warranty agreement between you and BINATONE regarding the Products or Accessories purchased by you, and supersede any prior agreement or representations, including representations made in any literature publications or promotional materials issued by BINATONE or representations made by any agent employee or staff of BINATONE, that may have been made in connection with the said purchase.

## CE DECLARATION



This product is in compliance with the essential requirements and other relevant provisions of the R&TTE directive 1999/5/EC.

Download User Guide from website: [www.verve.life](http://www.verve.life)



[www.motorolahome.com](http://www.motorolahome.com)

[www.verve.life](http://www.verve.life)

	<p><b>RECYCLING</b></p> <p>This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimise its impact on the environment.</p> <p>User has the choice to give his product to a competent recycling organisation or to the retailer when he buys a new electrical or electronic equipment.</p>
	<p><b>DC Voltage</b></p>

Manufactured, distributed, or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. Apple logo is a trademark of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google Play and Android are trademarks of Google Inc. All other trademarks are the property of their respective owners. © 2017 Motorola Mobility LLC. All rights reserved.



UK\_EU\_ROW\_EN Version 1.0  
Printed in China

Model number: CA001H